




Number of stays chart - L 164 mm



h	Kraby version	Door weight (Kg)												
		1	2	3	4	5	6	7	8		9	10	version	
230 - 274	Automatic	1x80N	2x8	ON	2x	120N		3x120N		4x120N			Automatic	
	Friction	1x45N		2x2	15N			2x60N			3x60N	Friction		
275 - 325	Automatic	1x80N	2x80N	1	2x12	ON.	3	4x120N				Automatic		
	Friction	1x60N	2	2x45N		2x60N		3x60N			4x60N	Friction		

Number of stays chart - L 244 mm



Rev. 02

																	INOV. OZ
h	Kraby version		Door weight (Kg)														
		1	2	3	4	5	6	3	7	8	9	10	1	1	12	13	version
300 - 324	Automatic	1x80N		2x50N		2x80N		2x100N		2x120N		2x140N		2x160N*		Automatic	
	Friction	1x45N		1x60N		2x45N	2x45N			2x60N				2x9	N		Friction
325 - 374	Automatic	1x80	1x80N		x50N 2x80		2x10	NOO	2x120N		2x140N		2x160N*			2x180N*	Automatic
	Friction	1x45N	1x45N 1x60N		2x45N	2x60N				2x90N					2x120N	Friction	
375 - 424	Automatic	1x80N	2x50N		2x80N	2x80N 2		2x100N		2x140N	2x1	2x160N*		80N* 2x240N*		40N*	Automatic
3/5 - 424	Friction	1x45N	1x45N 1x60N		2x45N	2x45N 2x			J		2x90N	2x90N		2x120N			Friction
425 - 474	Automatic	2x50N		2x80N			2x100N		2x120N	2x140N	0N 2x160N		2x180N*		1*	3x160N*	Automatic
	Friction	1x60N		2x45N		2)	2x60N			2x	90N		2x1	2x120N		3x90N	Friction
475 - 524	Automatic		2x80N		2x1	00N	00N 2x120N		2x140N	2x1	60N*		2x180N*		3x1	60N*	Automatic
	Friction	2x45N				2x60N 2			2x90N	2x120N 3x9			ON 3:			NC	Friction

^{*} Strenghts available on request.

Number of stays chart - L 355 mm



Rev. 02

h	Kraby version							Door	r weight	(Kg)								Kraby version
		1	2	3	4	5	6		7	8	3	9	10		11	12	13	
400 - 424	Automatic	1x80N			2x50N			2x80N				2x10	2x100N 2x120N			2x160N	Automatic	
	Friction	. "			2	2x45N								Friction				
425 - 474	Automatic	1x8	BON	2x50N	2x80N					2x10	2x100N 2x12			ON 2x160			N	Automatic
	Friction				2x451	2x45N							2x6	N			2x90N	Friction
475 - 524	Automatic	1x8	BON	2x50N	-	2x80N 2x			100N	00N 2x120N			2x16	2x160N 2x180			2x200N	Automatic
475 - 524	Friction	2x45N									2x60N 2x90N							Friction
525 - 574	Automatic	1x8	BON	2x50N	2x8	BON	2x10	NO	ON 2x100N			2x16	ON		2	(180N	2x200N	Automatic
323 - 374	Friction			2x45N	2x60N									2	x90N		Friction	
575 - 624	Automatic	2x5	ON	2x80N	2x1	00N	2x12	120N 2:			160N 2x1			ON		2x200	N	Automatic
373 - 624	Friction			2x45N	I	2x				60N					2x90N	I		Friction
625 - 700	Automatic	2x5	ON	2x80N	2x1	2x100N 2x1		ON.		2x16	60N 2:		2x18	80N 2x2		2x200	N	Automatic
025 - 700	Friction		2x451	V		2x60N						2x90N		2x120N				Friction








LIFT UP DRILLING PLANS WITH STANDARD HINGES OPENING WITH HANDLE









The dimensions of the above drilling plans refer to carcases which use standard sprung or unsprung hinges and mounting plates 0 mm. Please note that the opening angle shown data is purely indicative. It varies with respect to the hinge brand and adjustment carried out.










LIFT UP DRILLING PLANS WITH STANDARD HINGES PUSH TO OPEN

KRABY CONFIGURATOR:







The dimensions of the above drilling plans refer to carcases which use standard unsprung hinges and mounting plates 0 mm. Please note that the opening angle shown data is purely indicative. It varies with respect to the hinge brand and adjustment carried out.







Please note that utilization with standard sprung hinges and K Push Tech with buffer is also possible. In such case, after the door is initially released by K Push Tech, a manual opening approx. 7cm is required (in order to win the spring resistance). Consequently, the door will automatically open to the fullest.

32

- Visible or invisible version

For details refer to section

"PUSH CATCHES & MAGNETIC CATCHES".





KRABY SYSTEM LIFT UP

KRABY is a gas and oil stay to open flap doors. It has been conceived to be installed by using standard automatic drilling processes. It is available in three different lengths and several newton strengths to suit doors of any size.

It can be fixed directly on solid doors or wider aluminium frame section doors. For small aluminium sections a range of special adaptors is available. KRABY is available in:

- Automatic version: once you open the door, it continues to open gently and completely by itself.
- Friction version: once you open the door, the stay holds the door in any required position.

KRABY offers some relevant benefits:

- The rotary knob placed on the piston base plate can be used to adjust the opening angle and therefore to align nearby doors.
- By adjusting the position of the piston base plate within the "U" slot of the side bracket, it is possible to change the time in opening and closing of the door

All the parts (stay excluded) are in zinc alloy nickel plated and engineering plastic.











INSTALLATION



VERY IMPORTANT

The door bracket has to be placed in vertical position with the slot facing forwards.

recommended fixing countersunk head wood screws Ø3,5x16 mm or Euro thread screws.







VERY IMPORTANT

The side bracket has to be placed with the slot in horizontal position and the open end facing the wall.

ADJUSTMENTS



INCREASE OPENING ANGLE Rotate the rotary knob.



REDUCE OPENING ANGLE Move forward and backward the piston base plate in the bracket slot.





